



Key to Instruments

- S4 5 deg
- S4 10 deg
- S4 19 deg
- S4 26 deg
- S4 36 deg
- S4 50 deg
- S4 PAR MFL
- S4 PAR WFL
- S4 PARNEL
- WFL PAR 64 WFL
- CHROMA Q
- COLOR FORCE 72

Accessories

- SCROLLER

BLACKOUT	35'-0"	54
CYC	35'-0"	53
	34'-8"	52
	33'-6"	51
	33'-0"	50
#4 TRAVELER	32'-6"	49
#4 BORDER	32'-0"	48
	31'-6"	47
	31'-0"	46
	30'-6"	45
	30'-0"	44
	29'-6"	43
	29'-0"	42
#4 ELECTRIC	28'-6"	41
	28'-0"	40
	27'-0"	39
	26'-6"	38
	26'-0"	37
ORCHESTRA SHELL UNAVAILABLE FOR ANY PURPOSE		
#3 TRAVELER	23'-6"	36
#3 BORDER	23'-0"	35
	22'-6"	34
	22'-0"	33
	21'-6"	32
	21'-0"	31
#3 ELECTRIC	20'-6"	30
	20'-0"	29
	19'-0"	28
	18'-6"	27
	18'-0"	26
	17'-6"	25
	17'-0"	24
	16'-6"	23
#2 TRAVELER	16'-0"	22
	15'-6"	21
	14'-6"	20
ORCHESTRA SHELL UNAVAILABLE FOR ANY PURPOSE		
	11'-6"	19
#2 ELECTRIC	11'-0"	18
	10'-6"	17
	10'-0"	16
	9'-6"	15
	9'-0"	14
#1 TRAVELER	8'-6"	13
	8'-0"	12
#1 BORDER	7'-6"	11
	7'-0"	10
	6'-6"	9
	6'-0"	8
SCREEN	5'-6"	7
	5'-0"	6
#1 ELECTRIC	4'-0"	5
	3'-0"	4
	2'-6"	3
	1'-6"	2
MAIN CURTAIN	1'-0"	1

